






Product Description: Table Saw
Model Number: SPT99-12
Body Number: 0200008016
Version: A
Issue Date: 2019/06/24








Product Description: Table Saw

Model Number: SPT99-12

Body Number: 0200008016

Version: A

Issue Date: 2024/07/05






Product Description: Table Saw

Model Number: SPT99-12

Body Number: 0200008016


Version: A

Issue Date: 2019/06/24





Product Description: Table Saw
Model Number: SPT99-12
Body Number: 0200008016
Version: A
Issue Date: 2019/06/24



Service Part List_SPT99-12_Version A

No.	Product Model#	Part Number	Description	Qty
7	SPT99-12	5610361155	Pan head screw	1
8	SPT99-12	3580000025	Bushing	1
9	SPT99-12	5650710079	Plain washer	2
10	SPT99-12	5650710080	Plain washer	1
11	SPT99-12	5630352027	Self-locking nut	1
12	SPT99-12	2826622121	Rod	1
13	SPT99-12	2826622122	Rod	1
14	SPT99-12	5630352028	Connecting nut	1
15	SPT99-12	5630352029	Knurled nut	1
16	SPT99-12	5630352030	Knurled nut	1
17	SPT99-12	3660753044	Compression spring	2
18	SPT99-12	5650710094	Plain washer	4
19	SPT99-12	3706973053	Fixing plate	5
20	SPT99-12	5610361156	Pan head screw	10
23	SPT99-12	5610361157	Pan head screw	8
26	SPT99-12	3706973054	Pointer	1
27	SPT99-12	5610361192	Pan head screw	2
34	SPT99-12	5610361158	Pan head screw	4
35	SPT99-12	5650710079	Plain washer	4
41	SPT99-12	3706973062	Support bracket	1
42	SPT99-12	5610361193	Pan head screw	2
43	SPT99-12	3130253230	Support plate	1
44	SPT99-12	5610361158	Pan head screw	2
45	SPT99-12	5650710079	Plain washer	2
47	SPT99-12	0110227001	Motor assembly	1
48	SPT99-12	3130253231	Guard plate	1
49	SPT99-12	5610361160	Pan head screw	1
50	SPT99-12	5610361161	Hex screw	1
51	SPT99-12	3706973055	Rod	1
52	SPT99-12	3706973056	Rod	1
53	SPT99-12	5650710081	Spring washer	4
54	SPT99-12	5610361162	Hex screw	4
55	SPT99-12	3553285044	Threaded rod	1
56	SPT99-12	3570037005	Bevel gear	1
57	SPT99-12	5610361163	Pan head screw	1
58	SPT99-12	3580000026	Bushing	1
59	SPT99-12	3706973060	Support plate	1
60	SPT99-12	5610361164	Pan head screw	2
61	SPT99-12	5650710079	Plain washer	1
62	SPT99-12	5610361165	Hex screw	1
63	SPT99-12	5650710098	Plain washer	2
64	SPT99-12	5610361194	Lock screw	1
65	SPT99-12	3706973059	Support plate	1
66	SPT99-12	3553285045	Drive shaft	1
67	SPT99-12	3580000027	Bushing	1
68	SPT99-12	5690438036	Retaining ring	1
69	SPT99-12	3580000028	Bushing	1
70	SPT99-12	5690438044	Retaining ring	1
71	SPT99-12	3570037005	Bevel gear	1

Service Part List_SPT99-12_Version A

No.	Product Model#	Part Number	Description	Qty
72	SPT99-12	5610361163	Hex screw	1
73	SPT99-12	5610361164	Pan head screw	2
74	SPT99-12	3660753045	Torsion spring	1
75	SPT99-12	3706973057	Stop plate	1
76	SPT99-12	5610361166	Special screw	2
77	SPT99-12	3130253256	Guard plate	1
78	SPT99-12	5610361167	Pan head screw	2
79	SPT99-12	3580000029	Bushing	2
80	SPT99-12	3130253232	Support bracket	2
81	SPT99-12	5610361197	Lock screw	4
82	SPT99-12	4860645009	Grounding cable	1
83	SPT99-12	5650710082	Toothed lock washer	2
84	SPT99-12	5610361195	Pan head screw	2
85	SPT99-12	3800156004	Fabric	1
86	SPT99-12	5650710083	Plain washer	7
87	SPT99-12	5610361169	Pan head screw	7
88	SPT99-12	5650710083	Plain washer	4
89	SPT99-12	5610361169	Pan head screw	4
90	SPT99-12	3580000030	Stop plate	2
91	SPT99-12	5610361188	Pan head screw	2
92	SPT99-12	3130253258	Support plate	1
93	SPT99-12	5610361170	Hex screw	2
95	SPT99-12	3130253233	Spring plate	1
96	SPT99-12	5610361171	Pan head screw	2
103	SPT99-12	5660288015	Spring clip	1
104	SPT99-12	5660288016	Spring clip	1
105	SPT99-12	5610361169	Pan head screw	2
106	SPT99-12	5650710085	Plain washer	2
107	SPT99-12	5610361194	Hex screw	4
108	SPT99-12	5640322018	Clamping bolt	2
109	SPT99-12	5650710086	Plain washer	2
111	SPT99-12	3130253234	Bar holder	1
112	SPT99-12	5610361172	Pan head screw	4
113	SPT99-12	3130253235	Cam	2
114	SPT99-12	5650710087	Toothed lock washer	2
115	SPT99-12	5610361173	Pan head screw	2
116	SPT99-12	3130253236	Switch housing	1
117	SPT99-12	5610361174	Tapping screw	2
118	SPT99-12	3706973061	Front panel	1
119	SPT99-12	3130253237	Tapping screw	8
120	SPT99-12	5650710096	Plain washer	2
121	SPT99-12	3580000031	Bushing	1
122	SPT99-12	3130253238	Handle	1
123	SPT99-12	5610361175	Lock screw	1
124	SPT99-12	3660753046	Compression spring	1
125	SPT99-12	5650710088	Plain washer	2
126	SPT99-12	3130253239	Handwheel	1
127	SPT99-12	3130253240	Knob	1
128	SPT99-12	5650710089	Plain washer	1

Service Part List_SPT99-12_Version A

No.	Product Model#	Part Number	Description	Qty
129	SPT99-12	5650710090	Spring washer	1
130	SPT99-12	5610361176	Special screw	1
131	SPT99-12	5610361173	Pan head screw	1
132	SPT99-12	5610361177	Special screw	1
133	SPT99-12	5650710091	Toothed lock washer	1
134	SPT99-12	3130253241	Pointer	1
135	SPT99-12	5610361169	Pan head screw	1
139	SPT99-12	3130253242	Switch cover	1
140	SPT99-12	5610361178	Tapping screw	4
141	SPT99-12	4810237031	Power supply cord	1
142	SPT99-12	3130253243	Cable strain relief rail	2
143	SPT99-12	5610361195	Pan head screw	1
144	SPT99-12	5650710082	Toothed lock washer	1
145	SPT99-12	3580000032	Spindle flange	1
147	SPT99-12	3580000033	Clamping flange	1
148	SPT99-12	5630352031	Flange nut	1
149	SPT99-12	3130253244	Cover	1
150	SPT99-12	5680258016	Combination wrench	1
151	SPT99-12	5630352032	Wing nut	1
152	SPT99-12	3130253245	Cover	1
153	SPT99-12	5680258017	Socket wrench	1
154	SPT99-12	3130253246	Cable clip	1
155	SPT99-12	5610361179	Tapping screw	1
156	SPT99-12	5610361180	Pan head screw	4
157	SPT99-12	3130253247	Guard plate	1
158	SPT99-12	5610361181	Torsion spring	1
159	SPT99-12	3130253248	Fixing plate	2
160	SPT99-12	5610361169	Pan head screw	2
161	SPT99-12	5610361179	Tapping screw	3
162	SPT99-12	5650710097	Plain washer	3
163	SPT99-12	3130253259	Dust-cover holder	1
164	SPT99-12	3130253249	Wing screw	1
166	SPT99-12	5690438037	Retaining ring	1
167	SPT99-12	3130253250	Workpiece pusher	1
168	SPT99-12	3130253260	Dust collection tube	1
180	SPT99-12	5610361196	Lock screw	2
181	SPT99-12	5630352034	Self-locking nut	1
182	SPT99-12	5610361182	Hex screw	2
185	SPT99-12	3660753047	Spring plate	1
186	SPT99-12	5610361183	Pan head screw	1
189	SPT99-12	5610361184	Lock screw	4
229	SPT99-12	5650710092	Plain washer	1
230	SPT99-12	5610361185	Pan head screw	1
258	SPT99-12	2244472047	Warning label	1
259	SPT99-12	2244472048	Warning label	1
260	SPT99-12	2244472049	Warning label	1
261	SPT99-12	2244472050	Warning label	1
262	SPT99-12	2244472051	Nameplate	1
263	SPT99-12	2244472052	Warning label	1

Service Part List_SPT99-12_Version A

No.	Product Model#	Part Number	Description	Qty
264	SPT99-12	3130253251	Scale	1
801	SPT99-12	2826622123	Table	1
802	SPT99-12	2826622180	Edge guide	1
803	SPT99-12	2826622124	Mitre gauge	1
804	SPT99-12	2826622125	Protective cover	1
805	SPT99-12	2826622113	Safety device	1
806	SPT99-12	2826622139	Mounting insert	1
807	SPT99-12	2826622126	Riving knife	1
808	SPT99-12	2826622114	Front panel	1
812	SPT99-12	2826622128	Lock lever	1
813	SPT99-12	2826622115	Foot cover	1
814	SPT99-12	2826622129	Foot cover	1
815	SPT99-12	2826622130	Rod	1
821	SPT99-12	2826622116	Mounting rail	1
824	SPT99-12	2826622131	Sliding plate	1
825	SPT99-12	2826622132	Sliding plate	1
850	SPT99-12	2826622117	Wheel	2
851	SPT99-12	2826622133	Lock mechanism	1
852	SPT99-12	2826622134	Stand foot	2
853	SPT99-12	2826622118	Stand foot	1
854	SPT99-12	2826622135	Handle	1
855	SPT99-12	2826622136	Handle	1
896	SPT99-12	2826622119	Screw set	1
47/2	SPT99-12	2740476001	Stator	1
47/3	SPT99-12	2751155001	Rotor	1
47/13	SPT99-12	5700008030	Deep-groove ball bearing	1
47/14	SPT99-12	5700058006	Ball bearing	1
47/25	SPT99-12	3552851001	Oil drain plug	1
47/31	SPT99-12	5700013012	Ball bearing	1
47/42	SPT99-12	3422074001	Bearing plate	1
47/43	SPT99-12	3521052001	Guard plate	1
47/45	SPT99-12	3706626001	Cover	1
47/46	SPT99-12	3129240001	Device cap	2
47/47	SPT99-12	5690368001	O-ring	1
47/48	SPT99-12	3552841001	Collar	1
47/55	SPT99-12	5700058007	Ball bearing	1
47/59	SPT99-12	5610334001	Screw	1
47/60	SPT99-12	5690372001	O-ring	1
47/64	SPT99-12	5610325001	Contact screw	3
47/67	SPT99-12	5690376001	O ring	1
47/69	SPT99-12	5690378001	O-ring	1
47/71	SPT99-12	5610340001	Screw	4
47/73	SPT99-12	5650616001	Springwasher	2
47/74	SPT99-12	5690397001	Rubber gasket	1
47/75	SPT99-12	5690374001	Seal	1
47/78	SPT99-12	5690375001	Seal	1
47/81	SPT99-12	5620610001	Screw	2
47/82	SPT99-12	5690379001	O-ring	1
44/83	SPT99-12	5650622001	Washer	1

Service Part List_SPT99-12_Version A

No.	Product Model#	Part Number	Description	Qty
47/84	SPT99-12	5630312001	Nut	1
47/86	SPT99-12	5620609001	Screw	4
47/90	SPT99-12	3129151001	Bearing cover	1
47/91	SPT99-12	5610326001	Screw	4
810	SPT99-12	4960369001	Carbon-brush set	1
811	SPT99-12	2825981001	Motor housing	1
830	SPT99-12	3422211001	Gear case	1
834	SPT99-12	2825982001	Set of gears	1
870	SPT99-12	2825668001	Bearing assembly	1