





No.	Product Model#	Part Number	Description	Qty
1	3821-01	5610361095	Pan head screw	4
2	3821-01	5650710037	Spring lock washer	18
7	3821-01	5700382025	Ball bearing	1
13	3821-01	3660753026	Spring	1
14	3821-01	5700382026	Bearing	2
15	3821-01	2790501005	Gear housing	1
16	3821-01	5700382027	Bearing	1
17	3821-01	3130253098	Baffle	1
18	3821-01	2751218009	Armature	1
19	3821-01	5610361096	Pan head screw	2
20	3821-01	5650710050	Plain washer	1
21	3821-01	3130253099	Boot	1
22	3821-01	2740520009	Field	1
23	3821-01	3130253100	Motor housing	1
24	3821-01	5650710038	Plain washer	4
25	3821-01	5610361097	Pan head screw	4
26	3821-01	2244472035	Nameplate	1
28	3821-01	2800278008	Brush holder	2
29	3821-01	3660753027	Spring	2
30	3821-01	5610361098	Pan head screw	4
31	3821-01	3130253133	Cover	1
32	3821-01	5610361099	Pan head screw	5
33	3821-01	5610361100	Pan head screw	5
34	3821-01	3130253101	Handle	1
35	3821-01	5610361101	Pan head screw	5
36	3821-01	3130253102	Switch button	1
37	3821-01	4870696024	Switch	1
38	3821-01	3130253103	Cord clamp	1
39	3821-01	4810237019	Power supply cord	1
40	3821-01	4870696025	Switch	1
41	3821-01	3130253104	Cap	1
42	3821-01	3130253105	Grommet	1
43	3821-01	3130253106	Handle	1
44	3821-01	5650710039	Plain washer	14
45	3821-01	5650710053	Spring lock washer	16
46	3821-01	5610361102	Pan head screw	4
47	3821-01	3130253107	Carrying handle	1
48	3821-01	5610361103	Pan head screw	1
49	3821-01	4930857003	Post	1
50	3821-01	4891884001	Transformer	1
51	3821-01	3130253108	Trigger	1
52	3821-01	3130253096	Linkage	1
53	3821-01	5690438027	Seal	1
54	3821-01	3660753028	Spring	1
55	3821-01	3130253097	Switch button	1
57	3821-01	3130253109	Protection	1
66	3821-01	3130253110	Bumper	1
68	3821-01	5610361094	Pan head screw	5
70	3821-01	5640322006	Bolt	1
71	3821-01	3580000014	Flange	1
73	3821-01	3580000015	Flange	1
74	3821-01	5640322008	Bolt	4
75	3821-01	3130253111	Protection	1

No.	Product Model#	Part Number	Description	Qty
76	3821-01	3553285028	Shaft	1
77	3821-01	3660753029	Main spring	1
78	3821-01	3130253112	Dust connection	1
79	3821-01	3580000016	Spacer	1
80	3821-01	3422506021	Work table	1
82	3821-01	3130253113	Plate	1
83	3821-01	5610361104	Pan head screw	2
84	3821-01	3580000017	Sleeve	1
85	3821-01	3422506022	Linkage	1
86	3821-01	3130253114	Cap	1
87	3821-01	3580000018	Bushing	1
88	3821-01	5610361105	Set screw	1
90	3821-01	5670524014	Pin	1
92	3821-01	3660753032	Spring	1
93	3821-01	5670524015	Pin	1
94	3821-01	5630352015	Self-locking nut	2
95	3821-01	3130253115	Handle	1
96	3821-01	5650710040	Plain washer	1
102	3821-01	3553285029	Bracket	1
105	3821-01	5640322007	Stud	1
106	3821-01	5640322011	Stud	1
107	3821-01	5630352016	Nut	2
108	3821-01	5640322010	Bolt	2
109	3821-01	5610361106	Pan head screw	8
110	3821-01	3130253116	Insert	1
117	3821-01	5630352017	Self-locking nut	1
118	3821-01	5650710041	Washer	1
119	3821-01	3130253117	Fence	1
120	3821-01	3130253118	Slide fence	1
121	3821-01	5630352014	Nut	1
122	3821-01	5650710036	Spring washer	2
123	3821-01	5610361107	Set screw	2
124	3821-01	5680258009	Socket single-square wrench	1
125	3821-01	3130253119	Holder	1
126	3821-01	3130253120	Knob	1
127	3821-01	5610361108	Set screw	4
128	3821-01	5650710042	Spring washer	4
131	3821-01	3130253121	Bottom guard	1
132	3821-01	3130253122	Pointer	1
170	3821-01	3130253123	Protector	1
172	3821-01	4860645008	Wire	2
173	3821-01	2244472029	Warning label	1
174	3821-01	2244472030	Laser label	1
175	3821-01	2244472031	Warning label	1
176	3821-01	2244472032	Laser label	1
177	3821-01	2244472033	Warning label	1
178	3821-01	2244472028	Warning label	1
179	3821-01	5650710043	Spring washer	5
188	3821-01	5650710044	Washer	1
189	3821-01	5650710045	Corrugated washer	1
190	3821-01	3130253124	Wire clip	1
192	3821-01	5650710046	Washer	1
193	3821-01	5650710051	Washer	1

No.	Product Model#	Part Number	Description	Qty
194	3821-01	3130253125	Cover	1
195	3821-01	3130253126	Base	1
196	3821-01	2244472036	Marketing label	1
204	3821-01	5610361109	Screw	1
206	3821-01	5610361110	Screw	2
207	3821-01	5650710054	Washer	2
208	3821-01	3130253127	Knob	2
209	3821-01	5630352018	Nut	2
210	3821-01	3660753030	Spring	2
211	3821-01	3130253128	Clamp	2
212	3821-01	5610361113	Screw	2
213	3821-01	2244472034	Warning label	2
214	3821-01	3660753031	Spring	1
215	3821-01	3580000019	Bushing	2
216	3821-01	5650710048	Washer	2
217	3821-01	5650710052	Spring washer	2
218	3821-01	5610361111	Screw	2
235	3821-01	3130253129	Knob	2
237	3821-01	3130253130	Clamp block	1
238	3821-01	5650710055	Washer	2
239	3821-01	5650710049	Spring washer	2
240	3821-01	5610361112	Screw	2
241	3821-01	5640322009	Bolt	1
242	3821-01	3130253131	Lever foot	4
243	3821-01	3130253132	Clamp block	1
801	3821-01	4960384011	Brush set	1
802	3821-01	2780218001	Laser assembly	1
806	3821-01	2826622080	Miter handle assembly	1
807	3821-01	2826622084	Base assembly	1
808	3821-01	2826622081	Gear assembly	1
809	3821-01	2826622085	Miter lever assembly	1
810	3821-01	2826622082	Knife guard	1
11	3821-01	3130253283	Cap	1
12	3821-01	5670524029	Pin	1
58	3821-01	5650710103	Toothed lock washer	1
59	3821-01	5610361207	Pan head screw	1
91	3821-01	3422506042	Trunnion	1
97	3821-01	3130253284	Scale	1
98	3821-01	3130253285	Pointer	1
104	3821-01	3130253286	Pointer	1
165	3821-01	5610361208	Pan head screw	1
171	3821-01	5680258018	Blind Rivet	1
191	3821-01	5650710104	Washer	1
236	3821-01	2244472056	Label	1
653	3821-01	3800156005	Dust bag	1
654	3821-01	3130253287	Knob	1
655	3821-01	3403084008	Clamp	1
656	3821-01	3422506043	Extension Stand	1
657	3821-01	3130253288	Stop Block	1
658	3821-01	3706973065	Extension Shaft	1
659	3821-01	3130253289	Knob	1