



No.	Product Model#	Part Number	Description	Qty
1	JS313101	4870663002	Trigger Switch	1
2	JS313101	4960015017	Carbon Brush	2
3	JS313101	4810003244	Power Cord & Plug	1
4	JS313101	2826661001	Base Plate Set	1
5	JS313101	3650213001	Wire Guard	1
6	JS313101	2826663001	Roller Support Set	1